



MATHESON

The Gas Professionals

PARTICLE FILTERS



Instructions

*READ AND COMPLY WITH THESE INSTRUCTIONS BEFORE
INSTALLING, OPERATING, OR SERVICING*

Table of Contents

I. SERVICE1

II. TROUBLE SHOOTING2

III. LIMITED WARRANTY3

IV. USER RESPONSIBILITY4

V. SAFETY PRECAUTIONS5

VI. GENERAL DESCRIPTION6

VII. INSTALLATION7

VIII. OPERATING INSTRUCTIONS.....9

IX. MAINTENANCE9

X. SPECIFICATIONS10

I. SERVICE

General Service

A unit which is not functioning in a normal manner should be removed from service until such time that repairs or replacement can be made. Upon completion of repair, full testing should be performed to assure the user that the unit has been returned to its original operating parameters. MATHESON can repair or replace equipment. To arrange for repair or replacement service, call 1-800-828-4313 and ask for the Warranty Administrator. **No product will be received by MATHESON without indication of gas service and without proper return material authorization provided by the warranty administrator. (All repairs must be made by MATHESON or an assigned and approved facility to maintain any warranties or guarantees).**

If the unit is under an applicable warranty, return the unit to MATHESON for repair or replacement. To arrange for warranty service, call 1-800-828-4313 and ask for the Warranty Administrator. **No product will be received by MATHESON without indication of gas service and without proper return material authorization provided by the warranty administrator.**

If advised by the Warranty Administrator to return the product to MATHESON, prepare the product for shipment and write, in large lettering the RMA Number assigned by the Warranty Administrator on the outside of the box. Also, if required by the Warranty Administrator, supply the completed RMA form with the product. Make sure that the product is adequately packaged, in the original shipping container if possible, and shipped prepaid (MATHESON will not accept COD freight) with a description of the observed deficiency to the attention of the:

Warranty Administrator
MATHESON
166 Keystone Drive
Montgomeryville, PA 18936

The user is expected to periodically inspect the product for leaks, loose or worn parts, broken or non-functioning components and to address those situations immediately. If the user would require verbal assistance in ascertaining the potential of a problem with any MATHESON product, contact the local MATHESON branch for assistance or your MATHESON Sales Representative.

II. TROUBLE SHOOTING

1. Initial Tests

- 1.1 Remove the Filter unit from the package in which it was shipped. Examine closely the packaging for signs of abuse during shipment. Make sure that the end dust plugs are attached to the unit. If the packaging appears to be abused, or if the end plugs are not installed, arrange for return following the procedure set forth in the “SERVICE” Section.
- 1.2 For Filter units having VCR connections, examine the sealing surface for signs of abuse. If the sealing surfaces are scratched or otherwise damaged, arrange for return following the procedure set forth in the “SERVICE” Section.
- 1.3 Examine the packing slip for the unit(s) ordered. Make certain that the unit(s) shipped matches the unit ordered as verified by the packing slip.

2. After Installation and Operation

- 2.1 Filters are considered expendable parts. Over periods of use, to be determined by the user, it will become necessary to exchange the filter for a new one.

<p>Note: If the pressure drop across the filter exceeds a delta of 50% from the original value, it may be an indication that the filter needs to be replaced.</p>

- 2.2 Filters should be leak tested periodically, on a schedule provided by the user based on experience, for degradation of the seals used in installation by using one of the methods describe in the “INSTALLATION” Section.
- 2.3 Filters should be visibly inspected periodically, on a schedule provided by the user based on experience, for signs of corrosion or other abuse to filter housing.
- 2.4 Filters exhibiting any of the deficiencies listed in this subsection should be immediately removed from service and replaced.

III. LIMITED WARRANTY

This equipment is sold by MATHESON under the warranties set forth in the following paragraphs. Such warranties are extended only with respect to the purchase of this equipment directly from MATHESON or MATHESON's Authorized Agent as new merchandise and are extended to the first Buyer thereof other for than the purpose of resale.

For a period of one year from date of original delivery (ninety days in corrosive service) to Buyer or to Buyer's order, this equipment, is warranted to be free from functional defects in materials and workmanship and to conform to the description of this equipment contained in this manual and any accompanying labels and/or inserts, provided that this equipment is properly operated under the conditions of normal use and that regular and periodic maintenance and service is performed or replacements are made in accordance with the instructions provided. Expendable parts of this equipment are similarly warranted to be free from functional defects in materials and workmanship and to conform to the description of this equipment contained in this manual and any accompanying labels and/or inserts. The foregoing warranties shall not apply if the equipment has been repaired other than by MATHESON or a service facility designated by MATHESON, or if this equipment has not been operated and maintained in accordance with written instructions provided by MATHESON, or has been altered by anyone other than MATHESON, or if the equipment has been subject to abuse, misuse, negligence or accident.

MATHESON's sole and exclusive obligation and the Buyer's sole and exclusive remedy under the above warranties is limited to repairing or replacing, free of charge, at MATHESON's sole discretion, the equipment or part which is telephonically reported to be a problem to the local MATHESON Branch Location, and which if so advised, is returned with a written statement of the observed deficiency, not later than seven days after the expiration of the applicable warranty, to the MATHESON Gas Equipment Technology Center during normal business hours, transportation charges prepaid, and which, upon examination, is found to comply with the above warranties. The Buyer shall pay for return trip transportation charges for the equipment or part.

MATHESON shall not be otherwise liable for any damages including but not limited to incidental damages, consequential damages, or special damages, whether such damages result from negligence, breach of warranty or otherwise.

There are no express or implied warranties that extend beyond the warranties hereinabove set forth. MATHESON makes no warranty of merchantability or fitness for a particular purpose with respect to the equipment or parts thereof.

Acceptance of the equipment by the final buyer indicates the final buyer's acceptance of all warranties and limitations set forth above.

IV. USER RESPONSIBILITY

This equipment will perform in conformity with the description thereof contained in this manual and accompanying labels and/or inserts when installed, operated, maintained and repaired in accordance with the instructions provided. This equipment must be checked periodically, with the frequency of such inspections depending upon the scope of use. Damaged, worn or contaminated equipment should not be used. Parts that are broken, missing, plainly worn, distorted or contaminated should be replaced immediately. Should such repair or replacement become necessary, MATHESON recommends that a telephonic or written request for service advice be made to the MATHESON Equipment Engineering Group in Montgomeryville, Pennsylvania or to the nearest MATHESON branch location.

This equipment or any of its parts should not be altered without the prior written approval of MATHESON Equipment Engineering Group. The user of this equipment shall have the sole responsibility for any malfunction, which results from improper use, faulty maintenance, damage, improper repair or alteration by anyone other than MATHESON or a service facility designated by MATHESON. Further, the ultimate user of the equipment is responsible for the training and safe operation of the equipment by personnel in his/her employ.

V. SAFETY PRECAUTIONS

1. Many Specialty Gases are hazardous in nature. It is important that the user of the equipment carefully review the hazards associated with the gas to be used with the Filter unit. **Before installing the Filter unit into any system, refer to the MSDS that was shipped with the gas or on file in your facility, as to the specific hazards associated with the gas to be used in the system. Also, refer to all applicable inserts contained with the equipment for additional precautions and operating instructions.**
2. Before using any Filter unit on toxic, corrosive, pyrophoric, flammable or other type of hazardous gas, test the leak integrity of the filter using an inert gas.
3. Make certain that the filter purchased is suitable for the application intended. All Filter units supplied by MATHESON, a model number, and a pressure limitation label and/or stamping. Carefully review this information to establish the filter fit for service in the desired application.
4. Make certain that the equipment purchased or delivered to the ultimate end user conforms to the specifications of the user. The user is responsible for selecting equipment compatible with gases that are to be used, physical parameters of operation and performance and normal material compatibilities. Selection information can be found in MATHESON Catalogs, MATHESON Tech Briefs and in the MATHESON Gas Data Book. In addition, any MATHESON representative would be pleased to aid in the selection of specific equipment.
5. Before installation of the Filter unit into a system, note the direction of the flow arrow. Make certain that the arrow is in the same direction as the intended flow.
6. For Filter units supplied with NPT connections, use an approved method of pipe sealing (such as an approved Teflon tape material) on the connection threads and tighten no more than one and one-half turn past hand tight.

CAUTION: Do not over tighten. Over tightening may crack the fitting housing and/or the Filter unit

7. For Filter units supplied with compression tube connections, face and deburr the tubing to which the unit is to be attached. Following the manufacturer of the fittings recommendations for tightening the compression tube fitting make the connection. Most manufacturers of compression tube fittings recommend tightening the locking nut one quarter turn past hand tight.

CAUTION: Do not over tighten. Over tightening may obstruct the flow of gas through the tubing or the Filter unit.

8. For Filter units supplied with VCR type connections, make certain that the connection in the system will mate to the connections supplied on the Filter unit, before attempting installation.

CAUTION: Most VCR type connections require the use of an expendable gasket. This gasket is to be used once. Make sure that the material of the gasket used is compatible with the gases to be used.

VI. GENERAL DESCRIPTION

MATHESON Filters are designed for specific services. Make certain that the Filter ordered is compatible with the application and the gases and/or liquids to be filtered.

Filters function as physical barriers to particulates. The filters marketed by MATHESON use two main methods to accomplish this goal. These methods as well as the series numbers to which they pertain are listed below.

1. **DEPTH FILTERS (Model 6124, 6134, 6164, and 6187)**
2. **MEMBRANE FILTERS (Model 6190)**

Depth Filters generally consist of a fibrous wound material. Some may have a binder to reduce the amount of fibrous shedding occurring during use. Over time, the relative lower “depths” of the filter become increasingly more efficient as the particulate material is trapped. Generally these filters are rated for 0.2 micron particle retention.

Membrane Filters employ a flexible and porous membrane as the physical barrier. The membrane is either a flat single sheet or a pleated structure encased in a housing. The pore size of the unit is determined by physical measurement of the pores. The rating of the filter also takes into consideration the weak physical forces of attraction associated with this method of filtration. Generally these filters are rated for 0.01 micron particle retention.

NOTE: Filters are not purifiers. Filters remove only particulate matter from gases or liquids and do not remove chemical contaminants.

VII. INSTALLATION

For maximum performance and service life, the filter should be installed in a clean, dry atmosphere, relatively free of shock and vibration. Sufficient room for access to plumbing should be provided to facilitate maintenance. Fitting dust caps should be removed just prior to installation

1. Gas Connections

- 1.1 Ensure that the flow in the system in which the Filter unit(s) is/are to be installed is in the direction of the arrow indicated on the body of the Filter unit(s).
- 1.2 MATHESON supplies the Filter unit(s) with a variety of end connections. Use an approved method of sealing on the connection.

CAUTION: Do not over tighten. Over tightening may cause damage to the Filter unit(s).

- 1.2.1 For Filter units supplied with NPT connections, use an approved method of pipe sealing (such as an approved Teflon tape material) on the connection threads and tighten no more than one and one-half turns past hand tight.

CAUTION: Do not over tighten. Over tightening may crack the fitting housing and/or the Filter unit(s).

- 1.2.2 For Filter units supplied with compression tube connections, face and deburr the tubing to which the unit is to be attached. Following the manufacturer of the fittings recommendations for tightening the compression tube fitting make the connection. Most manufacturer compression tube fittings recommend tightening the locking nut one quarter turn past hand tight.

CAUTION: Do not over tighten. Over tightening may obstruct the flow of gas through the tubing or the Filter unit(s).

- 1.2.3 For Filter units supplied with VCR type connections, make certain that the connection in the system will mate to the connections supplied on the Filter unit, before attempting installation.

CAUTION: Most VCR type connections require the use of an expendable gasket. This gasket is to be used once. Make sure that the material of the gasket used is compatible with the gases to be used.

- 1.3 Use only pre-cleaned tubing or pipe and clean, dry (< 1.0 ppm H₂O) gases.
- 1.4 After Filter unit installation prior to the use of the unit, the plumbing system should be thoroughly leak tested using either an approved soap solution or by pressurizing the entire system with Helium and using an approved leak detector and monitor for a leak rate of less than 1×10^{-5} cc/sec He.

<p>NOTE: This step is required by the user when the Filter unit is to be used in any hazardous material applications, such as but not limited to, flammable, toxic, corrosive, or pyrophoric applications.</p>

2. Environmental Requirements

Refer to the "SPECIFICATIONS" section for the applicable Series of Filter.

3. Mounting

- 3.1 The filter units should be supported by some method compatible with the application and location of the unit in a gas or liquid line.
- 3.2 The Filter unit should NOT be supported by only the tube or pipe to which it is attached. This may cause radial or other stress to the connections securing the unit in the gas or liquid line.
- 3.3 The Filter unit will function regardless of the physical position of mounting (eg. horizontal, vertical or anywhere in between).

VIII. OPERATING INSTRUCTIONS

Read the "SAFETY PRECAUTIONS" and "INSTALLATION" sections before operation of the equipment.

1. After installation in the system and prior to operation, the system should be thoroughly leak checked (as described in Section VII, 1.4).
2. Begin to apply pressure to the system in a controlled manner using a regulator or other approved device for pressure regulation.
3. Within the system note the pressure before the filter in the line and after the filter in the line. Record this information in a secure place.

NOTE: All Filters experience some pressure drop across the point where they are installed. This is not uncommon and should be expected.

4. If there is sufficient flow and pressure across the filter, the system is now ready for operation.

IX. MAINTENANCE

1. Filters are expendable parts. No maintenance is required until the Filter unit exceeds the parameters listed in the TROUBLE SHOOTING Section. If the parameters are exceeded, it is time to replace the unit.
2. Filters that are secured in a line with VCR type fittings require additional attention. If the VCR seals are broken after original installation, the gasket employed is expendable and must be replaced to ensure leak tight operation.
3. The maintenance period should be established by the user based upon historical experience in the user's particular application.

X. SPECIFICATIONS

Model 6124, 6134, and 6164

Materials of Construction

- Body: 316 Stainless Steel
- Filter Elements: Fiberglass
- Filter Screens: 316 Stainless Steel

Specifications

- Maximum Operating Pressure: 250 psig
- Temperature Rating: 0 to 165°F (-18 to 74°C)
- Filtration Rating: 100% efficiency at 0.2 micron level
- Maximum Flow Rate: See chart

Part Number	Inlet/Outlet Connections	Max. Flow SLPM**	Dimensions (D x L)
Filters with Pipe Fittings			
SEQ6164P4FF	1/4" FNPT x FNPT	150	1.66" x 3.0"
SEQ6134P8FF	1/2" FNPT x FNPT	400	2.38" x 4.1"
SEQ6124P12FF	3/4" FNPT x FNPT	1000	2.38" x 7.5"

Filters with Standard Swagelok Fittings

SEQ6164T2FF	1/8" x 1/8"	30	1.66" x 4.9"
SEQ6164T4FF	1/4" x 1/4"	100	1.66" x 4.1"
SEQ6164T6FF	3/8" x 3/8"	150	1.66" x 4.3"
SEQ6134T4FF	1/4" x 1/4"	200	2.38" x 4.8"
SEQ6134T6FF	3/8" x 3/8"	400	2.38" x 5.0"
SEQ6134T8FF	1/2" x 1/2"	400	2.38" x 5.3"
SEQ6164T4MM*	1/4" tubing (316 SS)	75	1.66" x 4.95"

Filters with VCR or VCO Fittings

SEQ6164V4MM	1/4" VCR M x M	100	1.66" x 4.11"
SEQ6164O4MM	1/4" VCO M x M	100	1.66" x 3.81"
SEQ6134V8MM	1/2" VCR M x M	150	2.38" x 5.12"

**NOTE: This model is supplied with 1/4" tubing only, welded at each end*

*** @ 15 psig Inlet, Atmospheric Outlet*

Model 6187

Materials of Construction

- Body: 316 Stainless Steel
- Filter Elements: Fiberglass
- Filter Screens: 316 Stainless Steel

Specifications

- Maximum Operating Pressure: 2500 psig
- Temperature Rating: 350°F (176°C) max.
- Maximum Flow Rate: 20 SLPM (5 psi pressure differential)
- Pore Size: 0.2 micron

Model 6190

Materials of Construction

- Body: 316 Stainless Steel
- Membrane: Teflon supported and sealed by polypropylene end caps
- Seal: Teflon encapsulated silicone O-ring

Specifications

- Maximum Operating Pressure: 1000 psig
- Temperature Rating: 100°F (38°C) max.
- Maximum Flow Rate: 250 SLPM (15 psi pressure differential)
- Pore Size: 0.2 micron
- Filtration Rating: 100% efficiency at 0.01 micron level
- Effective Filter Area: 0.5 ft³



166 Keystone Drive
Montgomeryville, PA 18936
800-828-4313
www.mathesongas.com
INT-0068 rev D

Copyright 2021 Matheson Tri-Gas, Inc. All Rights Reserved.

All contents of this document are subject to change without notice and do not represent a commitment on the part of Matheson Tri-Gas, Inc. Every effort is made to ensure the accuracy of this information. However, due to differences in actual and ongoing operational processes and product improvements and revisions, Matheson Tri-Gas, Inc. cannot guarantee the accuracy of this material, nor can it accept responsibility for errors or omissions. This document is intended to serve as a general orientation and cannot be relied upon for a specific operation. No warranties of any nature are extended by the information contained in these copyrighted materials.

All names, products, and services mentioned herein are the trademarks or registered trademarks of their respective organizations and are the sole property of their respective owners. Matheson and the Matheson logo are registered trademarks of Matheson Tri-Gas, Inc.

TERMS AND CONDITIONS OF SALE

<https://shop.mathesongas.com/terms-and-conditions>