

# NANOCHEM<sup>®</sup>

## WK-Series (White Knight™) Gas Purifiers

### Overview

NANOCHEM® WK-Series (White Knight™) purifiers offer the highest lifetimes and the best impurity removal efficiencies in a very economical design. The in-line design enables a very compact footprint and allows drop-in replacement of competing hardware designs. The WK-Series is available in a number of sizes for point-of-use applications to bulk gas purification.

### Features and Benefits

- For point-of-use to bulk flow specialty gas purification
- **Highest Lifetimes**
- **Best Impurity Removal Efficiencies**
  - Removes critical contaminants to sub part-per-trillion levels
- Enhances manufacturing process economy and improves equipment performance
- Provides consistently high purity gas under fluctuating inlet impurity conditions
- Improves component lifetime and reduces particle generation by removing moisture from corrosive gases
- Compact footprint; inline design
- Easy to install and operate
- No heating or cooling required
- Quick start up
- All metal parts, type 316L stainless steel, or Nickel 200
- Economical, low cost of ownership



**MATHESON**  
The Gas Professionals

## Impurities Removed

Gas Type	Contaminants	Outlet Purity
Inerts - Nitrogen (N <sub>2</sub> ), Argon (Ar), other inerts	H <sub>2</sub> O	< 86 ppt
	O <sub>2</sub>	< 50 ppt
	CO	< 100 ppt
	CO <sub>2</sub>	< 10 ppt
	Benzene	764 ppq
	Toluene	938 ppq
	Ethylbenzene	746 ppq
	m, p - Xylene	426 ppq
	o - Xylene	689 ppq
	TMDSO	697 ppq
	Refractories*	< 697 ppq
	H <sub>2</sub>	< 1 ppb
Ammonia (NH <sub>3</sub> )	H <sub>2</sub> O	< 45 ppb
	O <sub>2</sub>	< 0.1 ppb
	CO <sub>2</sub>	< 11 ppb
	Carbamate	< 11 ppb
	GeH <sub>4</sub>	< 1 ppb
	SiH <sub>4</sub>	< 3 ppb
	Siloxanes	< 40 ppb
	<b>Metals</b>	
	Al	< 0.6 ppb
	Cu	< 0.27 ppb
	Fe	< 0.8 ppb
	K	< 0.35 ppb
	Na	< 0.27 ppb
	Si	< 1.3 ppb
	W	< 0.11 ppb
	Zn	< 0.27 ppb
	Zr	< 0.11 ppb
	<b>Hydrocarbons from Liquid NH<sub>3</sub></b>	
	Napthenic and Paraffins	85% removal
	Ethyl Benzene	96% removal
	Dissolved other HC	<200 ppb
	<b>Hydrocarbons from Gaseous NH<sub>3</sub></b>	
	n-Butane	<30 ppb
	Ethylbenzene	<30 ppb
Carbon Dioxide (Purifier material HCX)	Isopropyl Alcohol	200 ppt
	Acetone	93 ppt
	Propene	< 1 ppt
	Ethanol	< 1 ppt
	Carbon Disulfide	< 1 ppt
	Hexane	< 1 ppt
	Benzene	< 1 ppt

Gas Type	Contaminants	Outlet Purity
Carbon Dioxide (Purifier material HCX) <i>continued</i>	Heptane	< 1 ppt
	Toluene	< 1 ppt
	m,p-Xylene	< 1 ppt
	o-Xylene	< 1 ppt
	Ethyl Toluene	< 1 ppt
	1,3,5-Trimethyl Benzene	< 1 ppt
	1,2,4-Trimethyl Benzene	< 1 ppt
	DichloroBenzene	< 1 ppt
Silane (SiH <sub>4</sub> )	H <sub>2</sub> O	< 100 ppt
	O <sub>2</sub>	< 100 ppt
	CO <sub>2</sub>	< 100 ppt
	CO**	< 1 ppb
	Chlorosilanes, disilane, siloxanes, arsine, phosphine	
Hydrogen (H <sub>2</sub> )	H <sub>2</sub> O	< 100 ppt
	O <sub>2</sub>	< 100 ppt
	CO <sub>2</sub>	< 100 ppt
Methane (CH <sub>4</sub> )	CO**	< 1 ppb
Ethane (C <sub>2</sub> H <sub>6</sub> ), other HC	NOx, SOx, H <sub>2</sub> S	
Sulfur Hexafluoride (SF <sub>6</sub> )	H <sub>2</sub> O in inert gas	< 100 ppt
	O <sub>2</sub> in inert gas	< 100 ppt
	CO <sub>2</sub> in inert gas	< 100 ppt
Carbon Tetrafluoride (CF <sub>4</sub> )	H <sub>2</sub> O in sulfur hexafluoride	< 10 ppb
	O <sub>2</sub> in sulfur hexafluoride	< 10 ppb
Other Fluorocarbons	H <sub>2</sub> O in sulfur hexafluoride	< 10 ppb
	O <sub>2</sub> in sulfur hexafluoride	< 10 ppb
Oxygen (O <sub>2</sub> ),	H <sub>2</sub> O	< 10 ppb
Carbon Dioxide (CO <sub>2</sub> ),	H <sub>2</sub> O	< 10 ppb
Nitrous Oxide (N <sub>2</sub> O)	H <sub>2</sub> O	< 10 ppb
Carbon Monoxide (CO)	Metal Carbonyls: Fe, Ni	
Corrosives (HCl, HBr, Cl <sub>2</sub> , SiH <sub>2</sub> Cl <sub>2</sub> , SiHCl <sub>3</sub> , BCl <sub>3</sub> )	H <sub>2</sub> O in inert gas	< 1 ppb
	H <sub>2</sub> O in HBr	< 100 ppb
	H <sub>2</sub> O in HCl	< 100 ppb
	<b>Volatile Metals***</b>	
	Mo	< 4 ppb
	Ti	< 13 ppb
	Fe(CO) <sub>5</sub>	< 50 ppb

Impurity removal depends on purifier material and incoming gas specification

\*Refractories as TMDSO (Tetramethyldisiloxane)

\*\*CO is removed efficiently by OMX & OMX-Plus™ media at low flow rates (recommend 1/10 of normal flow rate)

\*\*\*Metals removed as measured on wafer via VPD-ICPMS:

Al, Ca, Cr, Fe, Mg, Ni, K, Na, Zn

Metals removal as demonstrated by intrinsic resistivity measurements on wafer grown by TCS:

Without MTX Purifier: <200 ohm-cm

With MTX Purifier: > 2500 ohm-cm and total metals on water <1E10 atoms/cm2

## Analytical Characterization of NANOCHEM® NHX™ Purifier

Impurity/Matrix	Capacity (L/L)	Efficiency (ppb)	Challenge (ppm)	Method
H <sub>2</sub> S in He	6	<0.3 (D/L)	50	GC-AED
H <sub>2</sub> S in Ar	31	<0.3 (D/L)	35	API-MS
H <sub>2</sub> S in NH <sub>3</sub>	25	<45 (D/L)	1000	FTIR
CO <sub>2</sub> in He	5	<11 (D/L)	500	GC-DID
CO <sub>2</sub> in NH <sub>3</sub>	—	<11 (D/L)	25	GC-DID
GeH <sub>4</sub> in N <sub>2</sub>	—	<0.1 (D/L)	2.5	API-MS
SiH <sub>4</sub> in N <sub>2</sub>	—	<0.1 (D/L)	2.5	API-MS
Siloxanes in N <sub>2</sub>	—	<-0.1 (D/L)	(trace)	API-MS
GeH <sub>4</sub> in NH <sub>3</sub>	—	<0.5 (D/L)	1.0	GC-AED
SiH <sub>4</sub> in NH <sub>3</sub>	—	<1 (D/L)	1.0	GC-AED
TEOS (siloxane) in NH <sub>3</sub>	—	<40 (D/L)	640	GC-DID
O <sub>2</sub> in NH <sub>3</sub>	—	<50 (D/L)	100	GC-DID

## Purifier Models

	WK-70 WK-75	WK-300	WK-500	WK-700	WK-2500	WK-5000
Media bed volume	50 ml 55 ml	300 ml	500 ml	700 ml	2500 ml	5000 ml
Maximum flow rate (in nitrogen), slpm (NM <sup>3</sup> /hr)	10 (0.6)	75 (4.5)	150 (9.0)	225 (13.5)	500 (30)	800 (48)
Pressure Drop at maximum flow rate (psi), tested in N <sub>2</sub> at 90 psi inlet	< 1 (<0.007 MPa)	TBD	< 5 (<0.04 MPa)	< 7 (<0.05 MPa)	< 5 (<0.04 MPa)	< 4 (<0.03 MPa)
Max permissible operating pressure, psi	1000 (7 MPa)	500 (3.5 MPa)	500 (3.5 MPa)	500 (3.5 MPa)	500 (3.5 MPa)	500 (3.5 MPa)



## Specifications

- 0.003 µm filter with 99.9999999% retention (PTFE or 316L SS)
- Internal surface finish < 15 µin Ra
- Maximum operating temperature is 40°C

## Connections


- Male inlet and outlet connections, 1/4" VCR - compatible

## Options


- Inlet and outlet isolation valves
- Three-valve manifold with isolation and bypass valves allows disconnection of purifier without interrupting process gas flow



## Dimensions




**NANOCHEM® Purifier Model WK-70**




**NANOCHEM® Purifier Model WK-75**


*\*actual media volume is 55 ml*




**NANOCHEM® Purifier Model WK-300**




**NANOCHEM® Purifier Model WK-500**



**NANOCHEM® Purifier Model WK-700**



**NANOCHEM® Purifier Model WK-2500**



**NANOCHEM® Purifier Model WK-5000**

*Dimensions in inches (mm)*

**Note: Purifiers are shown in horizontal position for illustration purposes only. Purifiers must be installed vertically.**

*Models WK-75, WK-300, WK-500, WK-700, WK-2500 and WK-5000 have a 0.003 µm particle filter.*

### Nanochem Purification

MATHESON

1861 Lefthand Circle

Longmont, Colorado 80501

Tel: 800-828-4313 • Fax: 215-619-0458

Email: [Info@mathesongas.com](mailto:Info@mathesongas.com)

Specifications are subject to change. Please check [www.mathesongas.com](http://www.mathesongas.com) for most current information.

Copyright 2023 Matheson Tri-Gas, Inc. All Rights Reserved.

All contents of this document are subject to change without notice and do not represent a commitment on the part of Matheson Tri-Gas, Inc. Every effort is made to ensure the accuracy of this information. However, due to differences in actual and ongoing operational processes and product improvements and revisions, Matheson Tri-Gas, Inc. cannot guarantee the accuracy of this material, nor can it accept responsibility for errors or omissions. This document is intended to serve as a general orientation and cannot be relied upon for a specific operation. No warranties of any nature are extended by the information contained in these copyrighted materials.

All names, products, and services mentioned herein are the trademarks or registered trademarks of their respective organizations and are the sole property of their respective owners. Matheson and the Matheson logo are registered trademarks of Matheson Tri-Gas, Inc.

White Knight is a trademark of Matheson Tri-Gas, Inc.

NANOCHEM is a registered trademark of Matheson Tri-Gas, Inc.

VCR is a registered trademark of Swagelok Company

Printed in USA PB037 R12/2023



**MATHESON**  
The Gas Professionals